



EXTRACTING SWIMMING KINEMATICS FROM HIGH-RESOLUTION DATA

Practical Lesson




ivodacosta11@gmail.com

LARGE PELAGIC FISH



OCEAN WARMING





LARGE PELAGIC FISH

FISHING PRESSURE

ARTICLE



<https://doi.org/10.1038/s41586-019-1444-4>

Global spatial risk assessment of sharks under the footprint of fisheries




INTRODUCTION


SCALES OF BEHAVIOUR



SCALES OF BEHAVIOUR




Movements of 1,681 oceanic and neritic pelagic sharks from 23 species - 2002 to 2017
globalsharkmovement.org





Satellite Tags


Sea surface temperature (°C)




SCALES OF BEHAVIOUR




Measuring deoxygenation effects on marine predators: A new animal-attached archival tag recording *in situ* dissolved oxygen, temperature, fine-scale movements and behaviour



da Costa et al. (2024) *Methods in Ecology and Evolution*
doi:10.1111/2041-210X.14360




Sharks and deoxygenation




Facultat de Biologia
BARCELONA

Sharks and deoxygenation




Climate-driven deoxygenation elevates fishing vulnerability for the ocean's widest ranging shark



7.91 — Dissolved oxygen (ml l⁻¹) at 100 m — 0.14

OMZ

Mid-Atlantic



Oceanographic model data

LIMITATIONS


- Most have relied on modelled DO data extracted from large, ocean-environmental databases (e.g., CMEMS; World Ocean Atlas)
- Long term information (days, monthly)
- Direct oxygen tolerances in environments impacted with climate change



Methods


1

DOME development conducted at BIOPOLIS CIBIO – Electric Blue CRL.



2

Calibration and standardisation of the DO measurements of each DOME tag. Pressure and drift tests.




3

Field tests were conducted off Faial islands in Azores.




Dissolved Oxygen MEasuring (DOME) archival tag



Oxygen calibrations and pressure tests


DRIFT TESTS



ACCURATE MEASUREMENTS




- Small mean difference between DOMÉ tag and factory-calibrated DO sensors (mean relative error of 5%).
- No temporal drift was observed over the 9-day test period.
- Dissolved oxygen measurements showed no variation with changes in pressure.

PRESSURE TESTS



Relating fine-scale behaviour to environmental gradients

VERTICAL BEHAVIOUR




AMBIENT DESCRIPTION

- DO concentrations ranging from 217 to 272 μmol L⁻¹; maximum at ~ 45 m
- Temperatures between 13°C and 23°C

BEHAVIOUR DESCRIPTION



- Vertical oscillations from surface to 404 meters depth
- 30 % of their time spent in high DO region

Relating fine-scale behaviour to environmental gradients



Relating fine-scale behaviour to environmental gradients

TAILBEAT FREQUENCY AND ACTIVITY LEVELS



COST-EFFECTIVE SWIMMING

- Blue sharks displayed vertical oscillations with faster tailbeats and increased activity during ascents when compared with descents
- Greater proportion of gliding during descents (but only ~20% of the time)

FORAGING STRATEGY

- High DO region: Maximum tailbeats and activity levels and higher proportion of burst swimming

Modelled vs in situ measurements




Mean *in situ* DO profiles by averaging daily oxygen measurements for both tagging and pop-off days.



Modelled DO profiles extracted from the grid cell ($0.25^\circ \times 0.25^\circ$) corresponding to the day and location of tagging/pop-off.

— *In situ* DO/temperature
— Modelled DO
— Modelled temperature




IMPROVE OCEAN MODELS

- CMEMS data generally underestimated *in situ* DO data by about 3% at deeper depths and by about 2% above 85 m.
- ‘Animal oceanographers’ to improve limited availability of *in situ* DO data





MULTISENSOR TAG

FINE-SCALE BEHAVIOUR AND METABOLIC RATES



MULTISENSOR TAG

FORAGING BEHAVIOUR



Watanabe et al. (2019). *Mar. Ecol. Prog. Ser.* 621:221-227





EXTRACTING SWIMMING KINEMATICS FROM HIGH-RESOLUTION DATA


ACCELERATION DATA

Static component – constant force of gravity.


Dynamic component – High frequency waves caused by dynamic movements such as caudal fin stroking and rapid turning.



TAG ORIENTATION





Other tags can have a different axis convention



EXTRACTING SWIMMING KINEMATICS FROM HIGH-RESOLUTION DATA

TAILBEAT SIGNAL


Tailbeat frequency – calculated from
dynamic component of sway




EXTRACTING SWIMMING KINEMATICS FROM HIGH-RESOLUTION DATA

SWIMMING ANGLES

Pitch angles – calculated from static component of surge






Roll angles – calculated from static component of sway and heave



EXTRACTING SWIMMING KINEMATICS FROM HIGH-RESOLUTION DATA


OVERALL DYNAMIC BODY ACCELERATION - ENERGY EXPENDITURE



Data Analysis using IGOR

1. INSTALL IGOR AND ETHOGRAPHER EXTENTION
2. IMPORT HIGH-RESOLUTION DATA
3. FILTER ACC WAVES
4. OVERALL DYNAMIC BODY ACCELERATION - **ODBA**
5. CALCULATE **PITCH** AND **ROLL** ANGLES
6. EXTRACT **TAILBEAT** SIGNAL
7. FILTER AND SAVE

FILES: bs_depth_data
bs_acc_data



Data Analysis using IGOR

1. INSTALL IGOR AND ETHOGRAPHER EXTENTION

1. Software Installation:

1.1. **Igor Pro:** Install Igor Pro from Wavemetrics:



License Activation: Follow the instructions provided by Wavemetrics to activate your Igor Pro license (for the class, use the free trial of 30 days)

2. Extension Installation:

2.1. **Ethographer***: extension on IGOR that enables bio-logging data to be viewed and analyzed


<https://sites.google.com/site/ethographer/download>

PLOS ONE

 OPEN ACCESS  PEER-REVIEWED

RESEARCH ARTICLE

Can Ethograms Be Automatically Generated Using Body Acceleration Data from Free-Ranging Birds?

Kentaro Q. Sakamoto , Katsufumi Sato, Mayumi Ishizuka, Yutaka Watanuki, Akinori Takahashi, Francis Daunt, Sarah Wanless

Published: April 30, 2009 • <https://doi.org/10.1371/journal.pone.0005379>

Data Analysis using IGOR

2. IMPORT HIGH RESOLUTION DATA

1. Load Data:

- In IGOR, navigate to **Data > Load waves > Load delimited text**.
- Select both "bs_depth_data.csv" and "bs_acc_data.csv" files.
- **Check** sampling frequency
- Confirm the values: 1 Hz (1 sec) for environmental data and 20 Hz (0.05 sec) for acceleration data.

2. Set Wave Scaling:


- To scale data, you need both starting datetime and sampling frequency
- Go to **Data > Change wave scaling**.
- Select **Date & Time** type, specify the start datetime, set the **Delta** which corresponds to the sampling frequency, and choose the variables to be scaled
- Separately for depth and acceleration (x,y,z) data

3. Plot timeseries (using Ethographer) to check if the end and start date of both files are correct:

- Go to **Misc > Run Ethographer** and then **Ethographer > Time series analysis**.



Data Analysis using IGOR

3. FILTER ACCELERATION WAVES



DYNAMIC ACCELERATION

Tailbeats, ODBA



STATIC ACCELERATION

Pitch, Roll

Data Analysis using IGOR

3. FILTER ACCELERATION WAVES

1. PSD Analysis:

- Go to **Windows > Procedure Windows > Procedure Windows**.
- Paste the following code: **#include <power spectral density>**
- Go to **Macros > psd >** select sway axis (accX) and segment alignment as 512 (or <).
- PSD plot will show up.
- **Peak** on frequency represent the average tail beat frequency
- You can also confirm by looking to the sway wave (lat.acceleration)
- **Lower peak** will be used to **remove static** part from the acceleration.

2. Static Acceleration Filter:

- Apply low-pass filter: Go to **Analysis > Filter > Apply low pass filter**.
- Select accX as the input data.
- Name the output wave "staticX".
- Set the "start of reject band" to the lower peak frequency identified in step 3c (e.g., 0.18).
- Set the "end pass band" to the lower peak frequency divided by 10 (e.g., 0.018).

2. Dynamic Acceleration:


- Go to Data > Duplicate wave; Names - dynamic; template wave - staticX
- Apply the formula on 'code' window: **dynamicX=accX-staticX**

Data Analysis using IGOR

4. ODBA

1. Calculate dynamic for the other axis (Y, Z)

- Follow the same steps as before
- Create a plot to check differences between raw acceleration vs static of each X,Y,Z
- Go to **Graph > Append traces to graph**.
- On the right side, select the "staticX" wave.
- In the lower "axis" tab, select the location of accX.
- In the left menu, select "calculated".



2. ODBA:

- Calculate Overall Dynamic Body Acceleration (ODBA):
- Create wave called 'odba' by duplicating 'staticX'
- Go to **Data > Duplicate wave**.
- Apply **ODBA** formula on 'code' window: **odba = abs(dynamicX)+abs(dynamicY)+abs(dynamicZ)**

Data Analysis using IGOR

5. PITCH AND ROLL ANGLES

1. Calculate Pitch from Static Acceleration:


- Go to **Data > Duplicate wave**.
- Create a new wave named pitch by duplicating "staticY".
- Apply pitch formula: **pitch = asin(staticY) * 180 / Pi**

2. Correct Pitch Angles (Kawatsu 2009 method):

- Calculate depth difference with the function: **CalcDif(depth,1)**
- Subsample pitch to 1Hz. Duplicate 'depth' (1Hz wave) with the name pitch1H
- Apply the function: **pitch1Hz = pitch(x)**
- Plot depth difference vs. pitch: **Window > New graph**
- Set ywave to "depth_Dif" and xwave to "pitch1Hz".
- Add linear regression: **Analysis > Quick fit > Line**.
- Find pitch at depth difference zero (attachment angle)
- Apply the formula: **pitch = pitch - attachment angle**

3. Calculate Roll from Static Acceleration:

- Go to Data > Duplicate wave static into 'roll' wave.
- Apply the roll formula**: **roll=atan(staticX/staticZ) * (180/Pi)**
- Correct Roll angles same way you did for pitch



Data Analysis using IGOR

6. TAILBEAT FREQUENCY

1. Perform Spectrum Analysis (others like CWT filter)

- Go to **Graph Toolbox > Spectrum Analysis**.
- Choose the desired acceleration wave (i.e., "dynamicX")
- To select the wave in SA, you need to have the wave selected on the plot window
- Set **minCycle** and **maxCycle** ranges based on your species and expected tailbeat frequency. Start with broad values (e.g., 0-12) for initial exploration, then refine based on observations.
- **Set time** range (all track or sections)
- Calculate spectrum: **Click Calc**.
- Visualize and customize: Adjust the plot color.

Data Analysis using IGOR

6. TAILBEAT FREQUENCY

2. Extract Tailbeat Signals using the Peak Tracer

- After running SA, select **Peak Tracer** option
- Adjust **threshold** and **entropy** (go for 50% and 90%, respectively)
- Experiment with different values to achieve a clean 'line' without excessive noise (peaks).
- Click **Save** to create DominantCycle (TB frequency) and DominantAmplitude (TB amplitude) waves with 1-second time intervals.
- Ensure the saved waves exhibit expected patterns and trends.

3. Noise Reduction on TBF (optional)

- Calculate TBF difference by applying a **mask: Mask analysis > Calc > Wave > Diff (central difference method)** to calculate the difference between consecutive values in the "DominantCycle" wave.
- **Make Analysis > Stats > Make Mask** and remove values from "DominantCycleDiff" that higher/lower than "-0.3 to 0.3" (as starting points, but adapt based on data distribution) – DifMask
- Select wave: DominantCycle_Dif, method: value; range: -0.3 – 0.3; output: DifMask
- **Mask Analysis > Misc > Convert Wave into XY:** wave – DominantCycle; mask – Dif Mask; select Timeseries; click on **Convert**
- It will create a filtered 'DominantCycle_select' wave

Data Analysis using IGOR

6. TAILBEAT FREQUENCY

4. Clustering Analysis: (split into different behaviours)

- Go to **Analysis > Clustering > K-Means clustering**.
- Set the number of clusters to **4** and click **Start**.

5. Identify periods of gliding (likely)

- Set the number of clusters to **20** and click **Start**.
- Identify curve with **lower signal (likely gliding)** – cluster number?
- Click **Save** to create a new wave named "Etho_Category".
- Go to **Make Analysis > Stats > Make Mask**, select Etho_Category and cluster number
- Choose the cluster corresponding to gliding.
- Refine gliding by selecting only periods **lasting more than 3 seconds**
- Use **Make Analysis > Calc > Event duration** with a minimum duration of 3 seconds and infinite maximum.

Data Analysis using IGOR

7. FILTER DATA AND SAVE

1. Create a mask for periods above 1 meter depth

- Go to **Make Analysis > Stats > Make Mask**, select **depth** and >2 to Inf.
- Name this mask as Surface
- **Mask Analysis > Misc > Convert Wave into XY**: wave – depth; mask – Dif Mask; select Timeseries
- It will create a filtered 'depth_select' wave (run for all the variables to clean surface noise -tag wobbling)

2. Build dataframe

- Go to **Window > New Table >** Select the variables that you want.
- **Save > Table Copy** (table window must be selected)